



INSTALLATION INSTRUCTIONS

Freestanding Bath Spout

PLEASE CAREFULLY READ THIS INSTRUCTION MANUAL BEFORE INSTALLING AND USING THE PRODUCT. PLEASE KEEP THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE.

This spout requires a separate mixer (e.g. wall mixer) installed to deliver mixed hot and cold water


- Spout must be installed by a licensed plumber
- Flush all plumbing prior to connecting the spout
- Install with pressure limiting valves and accessible isolating stop cocks
- Maximum water temperature 55°C
- Ideal operating pressure: 100 kpa to 500kpa
- Not recommended for gravity feed systems

Cleaning and Care

Care should be exercised when cleaning this product. Although its finish is durable, it can be damaged from abrasives and cleaning pads. To clean, use a light non-abrasive cleaning solution or cleaning polish.

- Do not use solvents, alcohol, chemicals or abrasives as they may irreparably damage the product surface
- Wash with soapy water and dry with a soft cloth
- For servicing, contact supplier

TOOLS REQUIRED




Plumbers' putty



Pipe tape




Philips screwdriver



Pliers



Adjustable wrench



1. Unscrew floor cover plate from the brass base plate
2. Installing plumber to connect mixed water supply to the input female threaded connection (1/2" BSP standard) at the base of the spout
3. Affix brass base plate to floor using supplied anchor bolts (or appropriate fixings) to position spout in the desired direction
4. Screw floor cover plate back onto base plate